

# Operation Manual

## THE ELIMINATOR™

### NSDPP38/40 POINT LOCATOR™ BALLISTIC NAILSCREW® DRIVER



## Universal Fastener Outsourcing BALLISTIC NAILSCREWS®

911-Nails.com (800) 352-0028 (479) 443-9292 Fax (800) 377-1109

### 34° PAPER COLLATED POINT LOCATOR™ NAILSCREWS® FOR MOST HIDDEN DECK CLIPS



SLIP IN CLIP

GUIDE TOOL

CONFIRM

PULL TRIGGER



500 BALLISTIC NAILSCREWS PER BOX - RECOMMENDED TOOL: NSDPP38/40

**"Drive them in, Screw them out!"™ \* "Quit Screwin' Around, Go Ballistic!"™**

**MANTIS™**

**TREX®  
HIDEAWAY™**

**CONCEAL  
Loc™**

**TC-G™**




*"The above trademarks belong to the related manufactures, UFO, LLC. is not affiliated with them"*

**PTPPNS112113SQ<sub>Black</sub>**  
**1-1/2" X .113 #1 SQ. DRIVE**  
**34° POINT LOCATOR™**  
**PAPER COLLATED STRIP**  
**PPG COATED FOR ACQ**  
**TREATED LUMBER**



500 BALLISTIC NAILSCREWS PER BOX - RECOMMENDED TOOL: NSDPP38/40



Place  
Ballistic Point  
& Pull Trigger



**POINT LOCATOR™ TOOL NSDPP38/40**



INCLUDES:  
CASE, HOSE FITTING  
& SAFETY GLASSES

90 Day Limited Warranty  
Parts & Service Department  
at [www.elder-hayesinc.com](http://www.elder-hayesinc.com)  
or call (800) 769-0775

Supplier details: This tool can be used to install the NailScrew at a 45° angle in any of the deck clips listed below.


- **Sure Drive USA MANTIS™**  
Installation Video At: [www.HowToNailScrew.com](http://www.HowToNailScrew.com)
- Tiger Claw TC-G (TC-150)
- TimberTech's CONCEALoc
- TREX® Hideaway hidden fastening systems for pre-grooved boards

The NSD can also be used to install joist hanger nails without modifications

“The lowest installed cost is the name of the game”

## IMPORTANT

It is very important that the intended operator of this tool Reads and understands this manual before operating this tool.



EC Machinery directive EN 792-13  
ANSI SNT – 101

**90 DAY LIMITED WARRANTY  
PARTS & SERVICE DEPARTMENT**

<http://www.elder-hayesinc.com> or call **1-800-769-0775**

**(ONLY USE PARTS AND ACCESSORIES RECOMMENDED BY THE MANUFACTURER)**

### Contents

- |                                  |                                       |
|----------------------------------|---------------------------------------|
| 1. Important safety instructions | 4. Maintenance                        |
| 2. Compressed air system         | 5. Troubleshooting when due to damage |
| 3. Operating instructions        |                                       |

## 1. Important safety instructions

This manual should be read carefully and understood completely by any person who intends to operate this tool. All instructions given should be adhered to accordingly as failure to comply may result in serious damage to the operator and/or the tool. The employer is responsible for enforcing the use of safety protection equipment by the tool operator and all other personnel in the work area.

- **Use safety glasses:** all persons in the work area must always wear safety glasses in order to prevent eye injuries.
- **Ear protection** must also be worn to prevent a possible hearing loss.
- **Use clean dry regulated compressed air** at the recommended pressure (given in the technical data).
- **Use only fasteners** made or recommended by the tool manufacturer (refer also to the technical data).
- **Never** exceed the maximum recommended operating pressure of this tool.
- **Never** use oxygen, carbon dioxide, combustible gases or any bottled gas as a power source.
- **Always disconnect** the air supply when doing any tool maintenance, cleaning a jam, moving location, leaving the work area or passing the tool.
- **Regularly inspect** the safety, the trigger and the springs for free unhindered movement, never use a tool that requires servicing.
- **Connect** the male free flow nipple to the tool side of the air line so that the tool is depressurized when disconnected from the hose.
- **Never** load fasteners with the trigger safety depressed as if the safety is bumped it will result in a fastener being fired.
- **Never** carry the tool with the safety depressed as if the safety is bumped then it will result in a fastener being fired.
- **Never** point the tool at yourself or at any one else.
- **Never** fire a fastener into a hard brittle surface such as concrete, steel or tiles.
- **Do not drive** fasteners too close to an edge or at too great an angle as the fastener may fly free or ricochet causing personal injury and damage.
- **Always** ensure that the work area is amply lit so as to avoid possible accidents caused by bad light.
- **Never** remove, tamper with or otherwise cause the tools operating controls to become inoperable.

## 2. Compressed air system

Proper use of the fastener driving tool requires an adequate quantity of clean dry compressed air. All compressed air contains moisture and other contaminants detrimental to the tool and so it is recommended to use an air line filter regulator lubricator as close to the tool as possible (within 15 feet (4.5m)). The filter should be well maintained so as to ensure optimum performance and power. All parts of the air supply system should be clean and contaminant free.

The tool shall only be connected to a compressed air line where the maximum allowable pressure cannot be exceeded by a factor of more than 10%, which can for example be achieved by a pressure reduction valve which includes a downstream safety valve.

A male free flow coupling should be connected to the tool side of the system with the female coupling providing a seal to prevent air loss from the compressor tank upon disconnection. Never connect a female disconnect coupling to the tool side as this provides a seal which prevents loss of compressed air from the air tank and if connected to the tool it could seal a charge of air in the tool which could lead to an unintentional actuation. Do not mount a swivel connector in the air supply line.

Different work pieces will require different operating pressures, the harder the wood the greater the pressure required. Remember always use the lowest pressure required for the work process at hand, this being to prevent unnecessarily high noise levels, increased wear and resulting failures.

**WARNING** *Keep hands and body away from the discharge area of the tool when connecting the air supply and always disconnect the tool when servicing, adjusting, cleaning and when the tool is not in use.*

### 3. Operating instructions

#### 3.1 Loading fasteners (refer also to the technical data)

Press the latch mechanism and open the magazine unit.

Load the fasteners into the magazine.

Close the magazine, (for queries contact your supplier).

#### 3.2 General operating instructions

##### 3.2.1 Types of actuating and triggering systems.

**For tools without a contact safety,**

##### *Single action actuation:*

An actuating system where the trigger has to be actuated for each driving operation.

##### *Single Sequential Trip fire :*

Fasteners can only be fired by first activating the contact safety (by holding the tool against the work piece) and then by squeezing the trigger, thereafter any further driving operations can only be actuated after the trigger has been returned to the starting position. The sequential trip tool allows exact fastener location without the possibility of driving a second fastener location without the possibility of driving a second fastener due to recoil.

##### 3.2.2 Operating procedures

**Protective equipment:** Before using any tool always ensure that you and those in the work area are using the appropriate working equipment

**Firing a fastener:** to fire a fastener hold the nose of the tool against the work piece, if the tool has a contact safety it will be necessary to push the tool forward so as to depress the safety, following which squeeze the trigger to fire a fastener.

Do multiple test runs with scraps of the actual materials that you intend to use before starting the deck (until the desired set is achieved).

**Exhaust air:** each time a fastener is driven a blast of air is exhausted from the top front area of the tool, keep your face clear of this, some tools incorporate a 360 exhaust, which enables you to control the direction of the exhaust gases.

**Depth control:** check whether the fastener has been driven into the work piece in accordance with the requirements, the driven depth can be controlled by adjusting air pressure only.

Drive fasteners tight, but **do not over drive or you will deform the clip. 70 to 80 psi recommended**

Always use the lowest possible air pressure for the following reasons,

- Save energy
- Less noise will be produced
- A reduction in fastener driving tool wear will be achieved

The new **UFO NSDPP38/40** installation tool drives a **UFO Ballistic NailScrew® (BNS)** in like a nail and can be removed like a traditional #1 SQ Robertson drive screw. The operator needs to perform only 4 easy steps.

- **Slip** the hidden deck fastener into the groove of the deck board directly above the joist.
- **Guide** the (NSD) NailScrew® Driver front forks so they line up on the clip so the tool is aligned with the joist.
- **Confirm** that the location of the white Ballistic point is in position directly above the hole to be filled with the (BNS) placement.
- **Pull** the trigger.



Any defective or improperly functioning tool must be immediately be disconnected from the compressed air supply and passed to a specialist for inspection.

### 3.3 Precautionary measures

- Always assume that the tool contains fasteners.
- Remove finger from the trigger when not driving fasteners. Never carry the tool with your finger on the trigger, as the tool will fire a fastener if the safety is bumped.
- Keep the tool pointed in a safe direction at all times, never pointing it toward yourself or others whether it contains fasteners or not.
- Never attempt, to drive a fastener into material that is too hard, or at too steep an angle or near the edge of the work piece, the fastener can ricochet causing personal injury. Remember, always hold nose right up to and firmly against the work material.
- Disconnect the tool from the air supply before performing any maintenance, leaving the work area, moving the tool to another location, or handing the tool to another person.
- Always, disconnect the tool before clearing any jams. To remove a jam just remove the driver guide cover plate or if applicable open the quick release and remove the obstructing nail.
- Carefully check the tool for proper operation of trigger and safety mechanism. Do not use the tool unless both the trigger and safety mechanism and any other of the operating control are functional or if the tool is leaking air or needs repair.
- Written approval of the tool manufacturer must be obtained prior to making any modifications to the tool.

## 4. Maintenance

### *‘Clean and inspect your tool every time you use it’*

The employer and tool operator are responsible for assuring that the tool is kept in safe working order. Furthermore only service personnel trained by the manufacturer, distributor, or employer shall repair the tool.

**CAUTION** Always remove the air supply before commencing any cleaning or inspection and remember to correct all the problems before beginning any repair work.

- Wipe tool clean and inspect tool for wear or damage. Use non-flammable cleaning solutions to wipe the tool. Never soak the tool in these solutions as they can cause internal damage.
- Always ensure that all of the screws are kept tight as loose screws can cause injury or can damage the tool.
- Tools requiring lubricant: If the tool is used without an in line lubricant then be sure to put in about 3 drops of lubricant at the start of each workday and 3 drops for every 1,000 fasteners fired thereafter.
- Tools shall be repaired or equipped only with parts or accessories that are supplied or recommended by the tool manufacturer / supplier.
- **NEVER** use a tool that requires repair work.

## 5. Troubleshooting and counter measures

Failure	Possible Causes	Check Method	Counter Measures
No nail is ejected	<b>Nail</b> <ul style="list-style-type: none"> <li>• Incorrect nails are loaded</li> <li>• Abnormal nails are loaded (large-sized head ,bent Incorrectly chained, etc.)</li> </ul>	<ul style="list-style-type: none"> <li>• Check if recommended nails are loaded</li> </ul>	<ul style="list-style-type: none"> <li>•Use recommended nails</li> <li>•Remove abnormal nails and load normal nails</li> </ul>
	<b>Magazine Unit</b> <ul style="list-style-type: none"> <li>• Push lever</li> <li>• Defective nail feeder(deflected, bent or broken)</li> <li>• Defective feed spring (worn or broken)</li> </ul>	<ul style="list-style-type: none"> <li>• Check for abnormalities of nail feeding portion (deflected, worn, deformed broken)</li> </ul>	
	<ul style="list-style-type: none"> <li>• Narrow or wide width of the Magazine groove</li> <li>• Worn nail head supporting portion of Magazine Abnormal nail guide groove of Blade Guide (deflected, deformed or broken)</li> </ul>	<ul style="list-style-type: none"> <li>• Load nails and confirm that they will move smoothly</li> </ul>	<ul style="list-style-type: none"> <li>•Repair deformed parts</li> <li>•Replace defective parts</li> </ul>

<b>Failure</b>	<b>Possible Causes</b>	<b>Check Method</b>	<b>Counter Measures</b>
No nail is ejected	<ul style="list-style-type: none"> <li>• Adhesive fragment or wood dust sticking on the Magazine or nail feeder</li> </ul>		<ul style="list-style-type: none"> <li>• Remove adhesive fragment or wood dust</li> </ul>
	<ul style="list-style-type: none"> <li>• Push lever</li> </ul>	<ul style="list-style-type: none"> <li>• Check push lever movement</li> </ul>	<ul style="list-style-type: none"> <li>• Replace</li> </ul>
	[Output unit: Piston or driver] <ul style="list-style-type: none"> <li>• Air pressure too low</li> </ul>	<ul style="list-style-type: none"> <li>• Carry out idle driving and check the return of the driver blade</li> </ul>	<ul style="list-style-type: none"> <li>• Check compressor</li> </ul>
	<ul style="list-style-type: none"> <li>• Worn piston ring</li> </ul>		<ul style="list-style-type: none"> <li>• Replace piston ring</li> </ul>
	<ul style="list-style-type: none"> <li>• Defective piston bumper</li> </ul>		<ul style="list-style-type: none"> <li>• Replace the piston bumper</li> </ul>
	<ul style="list-style-type: none"> <li>• Defective bumper piece (defective, worn or broken)</li> </ul>		<ul style="list-style-type: none"> <li>• Replace the piece</li> </ul>
	<ul style="list-style-type: none"> <li>• Defective O-ring (disconnected, deformed or broken)</li> </ul>		<ul style="list-style-type: none"> <li>• Reassemble or replace the o-ring</li> </ul>
	<ul style="list-style-type: none"> <li>• Defective driver blade, (deflected, deformed or broken)</li> </ul>	<ul style="list-style-type: none"> <li>• Replace</li> </ul>	
<ul style="list-style-type: none"> <li>• Defect inside cylinder (adhesive or wood fragment, worn)</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the nailer drives at minimum operating pressure</li> </ul>	<ul style="list-style-type: none"> <li>• Remove adhesive fragment or wood dust</li> </ul>	


<b>Failure</b>	<b>Possible causes</b>	<b>Check Method</b>	<b>Counter measures</b>
The driven nail is bent	<ul style="list-style-type: none"> <li>• Nails are inaccurately fed into the Blade Guide</li> <li>• Incorrect nails are loaded</li> </ul>	Refer to item above	<ul style="list-style-type: none"> <li>• Refer to item above</li> </ul>
	<ul style="list-style-type: none"> <li>• Worn driver blade</li> </ul>	Check if the driver blade is extremely worn or not	<ul style="list-style-type: none"> <li>• Replace the driver blade</li> </ul>
	<ul style="list-style-type: none"> <li>• The wood is too hard</li> </ul>	Check if the nails bend on softer wood or not	<ul style="list-style-type: none"> <li>• Stop using the tool</li> </ul>
The driven nails do not fully penetrate the work piece (heads protrude)	<ul style="list-style-type: none"> <li>• The wood is too hard</li> </ul>	-	<ul style="list-style-type: none"> <li>• Stop using the tool</li> </ul>
	<ul style="list-style-type: none"> <li>• Air pressure too low</li> </ul>	-	<ul style="list-style-type: none"> <li>• Adjust the air pressure</li> </ul>
	<ul style="list-style-type: none"> <li>• Worn or broken driver blade</li> </ul>	<ul style="list-style-type: none"> <li>• Carry out idle driving and check if the driver blade protrudes from the blade guide nose</li> </ul>	<ul style="list-style-type: none"> <li>• If the driver blade does not protrude from the blade guide replace</li> </ul>
	<ul style="list-style-type: none"> <li>• Incorrect driving depth adjustment</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the tip of the driver blade is excessively worn or not</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the guide plate to the appropriate position.</li> </ul>

<b>Failure</b>	<b>Possible causes</b>	<b>Check Method</b>	<b>Counter measures</b>
	<ul style="list-style-type: none"> <li>• Defective piston ring (worn or broken)</li> <li>• Defective inner surface of cylinder (worn or rough)</li> </ul>	<ul style="list-style-type: none"> <li>• Disassemble the output unit and check the inside and outside surfaces of the piston ring and cylinder</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the defective parts</li> </ul>
Nails clog within the ejecting gate	<ul style="list-style-type: none"> <li>• Nails are inaccurately fed into the blade guide</li> <li>• Incorrect nails are loaded</li> </ul>	<ul style="list-style-type: none"> <li>• Refer to first item</li> </ul>	<ul style="list-style-type: none"> <li>• Refer to first item</li> <li>• Use designated nails</li> </ul>
	<ul style="list-style-type: none"> <li>• Worn tip of the driver blade</li> </ul>	<ul style="list-style-type: none"> <li>• Carry out idle driving and check if blade tip if worn or not</li> </ul>	<ul style="list-style-type: none"> <li>• Replace</li> </ul>
	<ul style="list-style-type: none"> <li>• Worn guide groove of the blade guide</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wear of the blade guide</li> </ul>	<ul style="list-style-type: none"> <li>• Replace</li> </ul>
	<ul style="list-style-type: none"> <li>• Work piece material is too hard</li> </ul>		<ul style="list-style-type: none"> <li>• Stop using the tool</li> </ul>

## NSDPP38/40

ITEM	PART #	DESCRIPTION	ITEM	PART #	DESCRIPTION
101	920800	DEFLECTOR PAD	303	920540	O - RING
102	920801	DEFLECTOR	304	920637	DUSTY COVER
103	830612	O - RING	305	920320	AIR PLUG
104	920502	HEX.SOC.HD.SCREW	306	841006	ANGLE FITTING
105	920803	HEX.SOC.HD.BOLT	401	920828	O - RING
106	920805	SPRING RETAINER/ BELT CLIP	402	920829	O - RING
107	920849	CAP	403	920830	BASE / MUZZLE
108	920806	PACKING	404	920831	SPRING
109	920850	COMPRESSION SPRING	405	920860	NOSE PIECE
110	920851	SEAL	406	920833	BOLT ASSY
111	920852	O - RING	407	920834	BOLT ASSY
112	920853	HD.VALVE PISTON	408	920835	SAFETY GUIDE
113	920854	O - RING	409	920836	SAFETY SPRING
114	920813	PRESS RING	410	920837	SAFETY
115	920882	CYLINDER PRESS RING	411	920668	HEX.SOC.HD.BOLT
116	920855	O-RING	412	920324	HEX.SOC.HD.BOLT
117	830830	DRIVER UNIT	413	920838	HALF ROUND HD.HEX.BOLT
118	920817	O - RING	414	920839	MAGAZINE A
119	920857	CYLINDER	415	920840	LOCK NUT
120	920819	CYLINDER RING	416	920841	POSITIONING SHEET
121	920820	CYLINDER SPACER	417	920333	HALF ROUND HD.HEX.BOLT
122	920821	O - RING	418	920348	LOCK NUT
123	920822	BUMPER	419	920370	STOP NAIL PLATE
124	820569	COLLAR	420	920346	PROTECTING HOOD COVER
201	920519	O - RING	421	920842	STEEL CHANNEL
202	920521	O - RING	422	920843	SAFETY STOPPER
203	920520	PLUNGER CAP	423	920340	PROTECTING HOOD COVER
204	920523	VALVE PLUNGER	424	920336	PUSHER
205	920522	O - RING	425	920844	SPRING/ RIBBON SPRING
206	920524	O - RING	426	920845	ROLLING ELEMENT
207	920525	SPRING	427	920846	ROLL PIN
208	920823	PLUNGER	428	920339	SPRING
209	830623	O - RING	429	920343	HALF ROUND HD.HEX.BOLT
210	920528	TRIGGER VALVE HEAD	430	920861	HEX.SOC.HD.BOLT
211	920529	SPRING PIN	431	920572	FLAT WASHER
212	920824	SPRING PIN	432	920862	LATCH SPRING BUSHING
213	920530	SPRING PIN	433	920573	BOLT CAP
214	920825	SPRING	434	830833	BALL
215	920826	TRIGGER UNIT	435	830834	FLAT WASHER
301	841001	GUN BODY UNIT	436	830835	RUBBER PAD
302	920539	END CAP	437	830836	HEX.SOC.HD.SCREW

For Parts and Service: <http://www.elder-hayesinc.com> or call **1-800-769-0775**



# NSDPP38/40

For Parts and Service: <http://www.elder-hayesinc.com> or call 1-800-769-0775