

Please keep in mind these safety measures when using UFO Ballistic NailScrews® and NailScrew® Drivers:

1. Always keep your work area clean and uncluttered.
2. Provide adequate lighting for the work area.
3. Only operate Ballistic NailScrew® Drivers and equipment in safe environments. Do not use tools in wet, damp, or rainy locations.
4. Do not use Ballistic NailScrew® Drivers or other tools around flammable liquids or gases. Sparks may be produced, especially when used with metal applications.
5. Keep away from children or bystanders to prevent bodily injury. Ballistic NailScrews® may ricochet if not installed correctly or into the correct materials.
6. To prevent injury, never modify a Ballistic NailScrew® Driver in any way. Modifications to the tools will void the warranty.
7. Never hold a Ballistic NailScrew® Driver by the air hose. Keep hoses away from sharp objects, heat, oil, or moving parts.
8. Use the appropriate weight or exterior extension cords when needed for the air compressor.
9. Never use Ballistic NailScrew® Drivers when fatigued or under the influence of medications, drugs, or alcohol. Always be alert and attentive.
10. Wear appropriate clothing. Keep clothing, jewelry, gloves, hair, or other loose items away from moving parts in order to prevent them being caught resulting in injury.
11. Make sure the Ballistic NailScrew® Driver is pointed in a safe direction before plugging it in. Keep your hands away from the trigger, power switch, or nose when carrying.
12. Always wear proper safety equipment such as protective glasses, hard hat, safety shoes, etc.
13. Be careful to maintain balance and proper footing.
14. Store Ballistic NailScrew® Drivers in a dry, secure area when not in use. **Keep out of the reach of children or untrained personnel.**
15. Always unplug the Ballistic NailScrew® Driver from the power source and air compressor before making adjustments, changing accessories, or storing. If you are using a gas tool, remove the battery or gas cylinder.
16. Keep Ballistic NailScrew® Drivers properly maintained and lubricated.
17. Only use accessories recommended by Universal Fastener Outsourcing, LLC.
18. Only use the Ballistic NailScrew® Drivers recommended for the appropriate Ballistic NailScrew® length, size, and diameter.
19. Any repairs to Ballistic NailScrew® Drivers should be made by qualified personnel. Use only authorized parts. Contact Elder-Hayes, Inc. for tool parts and services at [www.elder-hayesinc.com](http://www.elder-hayesinc.com) or 800.769.0775.